









SİSTEM GÖRÜNÜŞÜ

TACER®



SİSTEM KESİT DETAYI





EBAT
SIZE

YANGIN SINIFI
FIRE PERFORMANCE

GERİ DÖNÜŞÜM
RECYCLED CONTENT

SES EMİLİMİ
SOUND ABSORPTION (NRC)

YÜZEY
SURFACE

SİSTEM AĞIRLIĞI
SYSTEM WEIGHT

PERFORASYON
PERFORATION

KALİTE BELGESİ
QUALITY

CONTACT



tacerakustik



tacerakustik



tacerinsaatt



tacerakustik

Head Office:

Birlik Mah. 450.Cad. No:79/B Çankaya/Ankara/TURKEY 06610
Tel: +90 312 496 11 05

İzmir Office:

Çınarlı Mah. Ozan Abay Cad. Ege Perla B-Blok No:10 Kat:6 D:65
Konak/İzmir/TURKEY 35170
Tel: +90 232 472 06 43

Factory 2:

O.S.B. Kızılırmak Cd. 1. Sk. No:15 Yahşıyan/Kırıkkale/TURKEY 71450
Tel: +90 318 321 33 50

İstanbul Office:

Esenboğa Mah. E-5 Yan yol Kelebek Sk. Marmara Kule No:17 Kat:12
Kartal/İstanbul/TURKEY 34870
Tel: +90 216 469 44 84

Factory 1:

Esenboğa Yolu 22 km. Saracalar Mah. Kümeevler Sk. No:46
Akyurt/Ankara/TURKEY 06750
Tel: +90 312 399 25 45

Factory 3:

Ostim Fabrika İvedik Org. San. Genç Kardeşler Sitesi 1468. Cad. 2286. Sok.
No:44-46-48-50
Ostim/Ankara/TURKEY 06378
Tel: +90 312 395 27 36

www.tacer.com.tr